LEARN QTY

A Software for Quantity, Cost Estimation & Project Control

By : Y.A. Agboatwala & Fatima.Y. Agboatwala 1802, Jamuna Amrut, 219, Patel Estate, S.V.Road, Jogeshwari(W), Mumbai - 400102 Phone: 09820792254, (022) 26783525 Url: www.supercivilcd.com, http://www.agboatwala.com Email : yaa@supercivilcd.com, yaa@agboatwala.com, supercivilcd@gmail.com

LEARN QTY

Create New File	♦ STEP NO. 1
Edit Items	♦ STEP NO. 2
Add Record	🔶 <u>STEP NO. 3</u>
Edit Quantities (Records)	♦ STEP NO. 4
Edit Material Coefficients	♦ STEP NO. 5
Edit Labour Coefficients	♦ STEP NO. 6
Summary (Display Results)	🔶 <u>STEP NO. 7</u>
Display Pie / Bar Charts	🔶 <u>STEP NO. 8</u>
Specifications	🤶 <u>STEP NO. 9</u>
Typical Forms/Formats	🔶 <u>STEP NO. 10</u>
Copy, Delete, Edit & Export to Excel.	🔶 <u>STEP NO. 11</u>
Monthly Cash Flow, Material, men,	🔶 <u>STEP NO. 12</u>

Consumption & S Curve.

IMPORTANT NOTE:

1. A USER SHOULD ALWAYS ENTER THE RATES OF ITEMS FOR WHICH HE HAS ADDED QUANTITIES. SINCE COST = RATE X QTY, IF EITHER ONE OF THEM IS NOT GIVEN, THEN ZERO COST WILL BE INDICATED. (STEP NO. 2, 3 & 4)

2. DO NOT EDIT MATERIAL OR LABOUR COEFFICIENTS UNLESS YOU HAVE SOME VALID REASONS TO DO SO. (STEP NO. 5 & 6)


3. THE MATERIAL COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL CEMENT, SAND, AGGREGATE & BRICK QUANTITIES ONLY.

THE LABOUR COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL MASON, CARPENTER, SKILLED LABOUR, UNSKILLED LABOUR & FOREMAN QUANTITIES.

4. THE ABOVE COEFFICIENTS ARE ALSO USED IN CALCULATION OF MONTHLY MATERIAL, LABOUR & CASH FLOW REQUIREMENTS AFTER USER HAS PREPARED THE PROJECT BAR CHART.

5. FOR RATE ANALYSIS OF VARIOUS ITEMS, OUR " SUPER RATE ANALYSIS " SOFTWARE COULD BE USED.

STEP NO. 1



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the FILE option in the MENU bar. The following window will open.

File Make New File Delete File Copy File Edit Project File Export QTY to Excel Gnatt Chart / Cash Flow Warranty Read Me Calculator Exit

Now click "Make New File" option. The following window will open.

Save As			?
Save jn: 崎	My Documents	💽 🖻 💆	
	6		Re da
File <u>n</u> ame:	1		<u>S</u> ave
Save as type:	(*.qty)	•	Cancel
ouro do gipo.			

• You must create a separate Folder / Directory to store your files.

Save As					? ×
Save jn: 🔂	1q	-		<u>r</u>	
] q1.QTY] Q2.qty					
File <u>n</u> ame:	QTY				<u>S</u> ave
Save as <u>t</u> ype:	(*.qty)		-		Cancel
	C Open as read-only				

I have created a Directory called 1q in C drive to store my QTY files. Now go to this folder & give a file name to your project. I have given "QTY" as the name of my new project file. Click the save button.

(Note: QTY is a project file, it has got no connection with QTY software.)

You will see in above window that I had created earlier q1 & q2 as my previous two projects.

When you click the save button, following window will open.

🖷 Project File : Add Project Deta	iils		×
File Name : C:\1q\QTY.qty			Date: 8/8/05
Organization :	Name of your company	i	1
Project :	G + 1 storey Building		1
Project No :	4305		
Client ID :	M/S Real Estate Corp.		
Building / Structure ID :	B1		1
Project Duration in Months :	24	Project Over Head in %	10
Taxes in %	5	Profit Margin in %	10
Rate per Cement Bag	200	Rate per M3 of Sand	600
Rate per M3 of Aggregates	600	Rate per Brick	1.0
Mason Wage/day	250	Carpenter Wage / day	250
Skill labour Wage / day	250	Un Skilled Labour Wage	180
Foreman Cost / day	350	Mobilization Advance in	% 10
Recovery of Advance in %	10	Security Deposit in %	10
	<u>0</u> K		

The window requires various project details. Whatever values you will fill here will serve as default values for the project.


I have filled up the above values as required by my new project QTY. You can change these values now OR later by clicking "Edit Project File" option in File Menu. Now click the OK button, following window will appear.



Click OK button. Now project File creation is complete.
 The above window gives the following two vital information.
 Use Edit I tem Menu to Fill Rates of various I tems &
 Use Add Becard Menu to add Overtities of various I tems &

2. Use Add Record Menu to add Quantities of various Items.

STEP NO. 2



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Edit Item option in the MENU bar. The following window will open.

Open			? ×
Look in: 🔂	1q	- 🗈 💈	2 🖻 🔳
3 q1.QTY 2 Q2.qty 2 QTY.qty			
l File <u>n</u> ame:	QTY.qty		<u>O</u> pen
Files of <u>type</u> :	(*.QTY)	•	Cancel
	C Open as read-only		

Now click QTY file & click open. A new window with all Sections will appear as follows. The heading is Edit / Delete Items - Double Click any option. This we will call Item Menu.

Edit / Delete of Items - Double Click Any Option	×
Section A: Preparatory Work	
Section B: Earth Work / Anti Termite Treatment	
Section C: Mortars	
Section D: Plain Cement Concrete	
Section E: Reinforced Cement Concrete	
Section F: Brick Masonry Work	
Section G: Stone Work	
Section H: Marble Work	
Section I: Wood Work	
Section J: Door & Window Hardware	
Section K: Structural Steel Work	
Section L: Flooring and Skirting	
Section M: Roofing/Terracing/Ceiling/RW Pipe	
Section N: Finishing / Plastering / Pointing	
Section P: Painting and Polishing	
Section Q: Building Repairs	
Section R: Dismantling & Demolishing	
Section S: Miscellaneous Works	
Section T: Road Work	
Section U: Horticulture & Landscaping	
Section V: Sanitary Installations	
Section W: Water Supply	
Section X: Drainage and Sewage	
Section Y: Pile Work	
Section Z: Water Proofing	
Section AA: Bridge Works	

Now double click " Section A: Preparatory Work ". A new window will appear as follows. This is main window which can perform the following functions.

Display all items.

- Print all items.
- Add your own items.
- Delete any existing item.
- Add Material, Labour, Subcontractor & Equipment Rates.

• One more field called " Item_ID " is given, in case you want to identify items apart from the existing Item No.

You can select any item from A1 to A22 by taking the Blue cursor to that item row or just clicking with the mouse on any item row.

DISPLAY/EDIT/DELETION/ADDITION OF ITEMS

Project No : 4305

Section A: Preparatory Work

Date : 8/8/05

1		Item	Unit	Material R	Labour Rate	Subcontra	Equipment
1	A1	CLEARING OF JUNGLE	M2				
	A2	CLEARING GRASS	M2	0.0000000000000000000000000000000000000	C. 60, 20, 60, 50, 51, 60		100000.0000000000000000000000000000000
	A3	FELLING TREES AVERAGE GIRTH 45 CMS	Nos				
1	A4	FELLING TREES AVERAGE GIRTH 90 CMS	Nos				
4	A5	FELLING TREES AVERAGE GIRTH 180 CMS	Nos				
1	A6	FELLING TREES AVERAGE GIRTH 300 CMS	Nos				· · · · · · · · · · · · · · · · · · ·
1	A7	SURFACE DRESSING : SOFT / LOOSE SOIL	M2				
1	A8	SURFACE DRESSING : HARD / DENSE SOIL	M2				
1	A9	BORING UP TO 6.0 M DEPTH	M				
1	A10	BORING 6.0 M < DEPTH < 12.0 M	M				
1	A11	BORING 12.0 M < DEPTH < 18.0 M	M				
1	A12	PROVIDING AND PLACING FILTER	M				
1	A13	G. I. PIPE FOR TUBEWELL	M				
4	A14	PROVIDING AND PLACING HAND PUMP	Nos				
1	A15	PLOUGHING EXISTING GROUND	M2				
4	A16	HOLE EXCAVATION IN ALL TYPES OF SOIL	Nos				
4	A17	HOLE EXCAVATION IN SOFT ROCK WITH	Nos				
1	A18	HOLE EXCAVATION IN SOFT ROCK WITH	Nos				
1	A19	HOLE EXCAVATION IN HARD ROCK WITH	Nos				
1	A20	HOLE EXCAVATION IN HARD ROCK WITH	Nos				
1	A21	SUPPLY AND ERECTION OF WATER TANK	Litre				
1	A22	TEMPORARY FENCE CONSTRUCTION	M				

We will select item A1. Enter Labour Rate = 3.0 Material Rate = 0.0 or leave it as it is. Subcontractor Rate = 0.0 or leave it as it is. Equipment Rate = 0.0 or leave it as it is.

Now Click UPDATE button.

You will see that I tem Rate (With Pink background) will change to 3.75. Final window will look like as follows.

DISPLAY/EDIT/DELETION/ADDITION OF ITEMS

Project No : 4305

Section A: Preparatory Work

Date : 8/8/05

A A: A: A:	1		Unit	Material R	Labour Rate	Subcontra	Equipment
A		CLEARING OF JUNGLE	M2		3		Second second
	2	CLEARING GRASS	M2		1.1		
A	3	FELLING TREES AVERAGE GIRTH 45 CMS	Nos				
	4	FELLING TREES AVERAGE GIRTH 90 CMS	Nos				
A	5	FELLING TREES AVERAGE GIRTH 180 CMS	Nos				
A	.6	FELLING TREES AVERAGE GIRTH 300 CMS	Nos				
A	7	SURFACE DRESSING : SOFT / LOOSE SOIL	M2				
A	8	SURFACE DRESSING : HARD / DENSE SOIL	M2				
A	9	BORING UP TO 6.0 M DEPTH	M				
A	10	BORING 6.0 M < DEPTH < 12.0 M	M				
A	11	BORING 12.0 M < DEPTH < 18.0 M	M				
A	12	PROVIDING AND PLACING FILTER	M				
A	13	G. I. PIPE FOR TUBEWELL	M				
A	14	PROVIDING AND PLACING HAND PUMP	Nos				
A	15	PLOUGHING EXISTING GROUND	M2				
A	16	HOLE EXCAVATION IN ALL TYPES OF SOIL	Nos				
A	17	HOLE EXCAVATION IN SOFT ROCK WITH	Nos				
A	18	HOLE EXCAVATION IN SOFT ROCK WITH	Nos				
A	19	HOLE EXCAVATION IN HARD ROCK WITH	Nos				
A	20	HOLE EXCAVATION IN HARD ROCK WITH	Nos				
A	21	SUPPLY AND ERECTION OF WATER TANK	Litre				
A	22	TEMPORARY FENCE CONSTRUCTION	M				


Similarly you can give Rates of more items, which are likely to be used in the project. Always click UPDATE button to see the final rate. This final Item Rate is arrived at after adding Overheads, Taxes & Profit margin.

Now Click the EXIT button to leave this window.

You are back to Item Menu. Here you can select other sections by double clicking any section & add the item rates of various items which you think will be required for your project.

STEP NO. 2 IS OVER.

STEP NO. 3



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2


Click the Add Record option in the MENU bar. The following window will open.

Open			? ×
Look in: 🔂	19	- 🗈 💆	📸 📰 🖽
a1.QTY Q2.qty			
File <u>n</u> ame:	QTY.qty		<u>O</u> pen
Files of type:	(*.QTY)	T	Cancel
	🗖 Open as <u>r</u> ead-only		1

Now click QTY file & click open. A new window with all Sections will appear as follows. The heading is Add Quantities - Double Click any Section. This we will call Add Menu.

🐃 Add Quantities - Double Click Any Section	X
Section A: Preparatory Work	
Section B: Earth Work / Anti Termite Treatment	
Section C: Mortars	
Section D: Plain Cement Concrete	
Section E: Reinforced Cement Concrete	
Section F: Brick Masonry Work	
Section G: Stone Work	
Section H: Marble Work	
Section I: Wood Work	
Section J: Door & Window Hardware Section K: Structural Steel Work	
Section L: Flooring and Skirting	
Section M: Roofing/Terracing/Ceiling/RW Pipe	
Section N: Finishing / Plastering / Pointing	
Section P: Painting and Polishing	
Section Q: Building Repairs	
Section R: Dismantling & Demolishing	
Section S: Miscellaneous Works	
Section T: Road Work	
Section U: Horticulture & Landscaping	
Section V: Sanitary Installations	
Section W: Water Supply	
Section X: Drainage and Sewage	
Section Y: Pile Work	
Section Z: Water Proofing	
Section AA: Bridge Works	
Double Click Any Option	
EXIT	

Now double click "Section A: Preparatory Work ". A new window will appear, which will display all the items under section A, as shown in following graphics.



Now double click the item "A1 CLEARING OF JUNGLE ". A new menu will appear with the heading of Add Quantities, as shown below.

🐃 Add Quantities 🔀 🔀
Section A: Preparatory Work
File Name C:\1q\QTY.00A
Record No. 1
Item ID :
Item No. A1
ITEM: CLEARING OF JUNGLE
Item Referance
Length in M
Width in M
Numbers
EXIT ITEM ADD QTY
Quantity in M2

Fill the various fields in the above window & click ADD QTY button.

If you want to deduct any QTY then give "Numbers " field a negative number.

• If you want to add another record then press " NEXT " button.

• Press " EXIT ITEM " button to exit this item.

Now you will be back to item menu. You can select another item for adding record OR you can exit this menu by pressing " EXIT " button.


Now you will be back to Add menu. You can select another Section for adding record OR you can exit this menu by pressing "EXIT " button.

🖷 Add Quantities	×
Section A: Preparatory	/ Work
File Name C:\1q\QTY.00A	
Record No. 1	
Item ID :	
Item No. A1	
ITEM: CLEARING OF JUNGLE	
Item Referance	P23
Length in M	30
Width in M	20
Numbers	2
EXIT ITEM	NEXT
Quantity in M2	1200

I have added various information to various fields. The final window will look like the graphic shown above.

STEP NO. 3 IS OVER.

STEP NO. 4



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Edit Quantities option in the MENU bar. The following window will open.

Open				? ×
Look in: 🔂	19	<u> </u>	2 📩	
a1.QTY Q2.qty QTY.qty				
j File <u>n</u> ame:	QTY.qty			<u>O</u> pen
Files of <u>type</u> :			•	Cancel
	C Open as read-only			1

Now click QTY file & click open. A new window with all Sections will appear as follows. The heading is Edit / Delete / Copy Menu - Double Click any option.

Edit / Delete / Copy Men	nu - Double Click Any Option	×
Section A: Preparator	ry Work	
	Anti Termite Treatment	
Section C: Mortars		
Section D: Plain Ceme		
Section E: Reinforced		
Section F: Brick Maso		
Section G: Stone Worl		
Section H: Marble Wo	5.55	
Section I: Wood Work		
Section J: Door & Win		
Section K: Structural		
Section L: Flooring an		
	erracing/Ceiling/RW Pipe	
	Plastering / Pointing	
Section P: Painting an		
Section Q: Building Re		
Section R: Dismantlin		
Section S: Miscellane		
Section T: Road Work		
Section U: Horticultur		
Section V: Sanitary In		
Section W: Water Sup		
Section X: Drainage a	ind Sewage	
Section Y: Pile Work	· ·	
Section Z: Water Proc		
Section AA: Bridge Wo	orks	

Now double click " Section A: Preparatory Work ". A new window will appear as follows, listing all the quantity records. Since I have added only one record, the following graphics will displays that record.

SECTIONAL DISPLAY/EDIT/DELETION/COPYING OF RECORDS

	It	Item	Reference	Unit	Nos	L	w	D	Quantity	Remark	
	A1	CLEARING OF JUNGLE	P23	M2	2	30	20	0	1200		
				5000 (AM (AC))	1	0/22/23	1000				
4							_				_
+				-	-		_		_		
+				-							-
+					-		-				-
1							1				
1											
						2					
	_			_							
_				_			_				_
+	_			-	-	-	-	-			-
+					-		-				-
+		-			-						-
1					-		-				
1											
		-			_	-					_
-	_			_	-		-	-			-
+				-	-			-			-
4		Comment control				-					_
it	Reco	ord No. 1									-
.f.	eren	ce : p23	Edit Nos 2		L:	20	-	₩: 2	0	D: 0	-
	eren	ce: p23	Luit nus 2			30		. 2	U	o. In	

The above window is very important tool, which can perform the following functions.

By Clicking " COPY" button, the selected record will get appended at the bottom of List.

By Clicking " REMOVE " button, the selected record will be deleted.

• By Clicking " MOVE UP " or " MOVE DOWN " buttons, the selected record will move up or down.

• By Clicking " PRINT " button, all the records will be printed.

• The most important option available here is Editing. At the base of window there is a heading in RED which says " Edit Record no. 1 ".

Just change the various fields (Values in the text boxes) & it will get reflected in the selected ROW above.

Click " UPDATE " button to recalculate quantities.

I have changed the various fields, the final display is given in following graphics.

SECTIONAL DISPLAY/EDIT/DELETION/COPYING OF RECORDS

Project No: 4305

Section A: Preparatory Work

Date: 9/8/05

	n	Reference	Unit	Nos	L	W	D	Quantity	Remark	
A1 CLE	ARING OF JUNGLE	P 45	M2	1	25	20	0	500		
100 C			100	1000	-	and the second	a state			
			_							
			_	_						
			-		1					_
			_	_		_				
			-	-		-				_
			-	-		-	-	_		-
						-				
			-	-		-				
		-		-		-	-			
			-	-		-				-
			-	-		-	-	-	+	-
			-	-		-	-	-		-
		-	-	-		-	-			-
			-	-		-				-
				-						-
				-		-				-
				-	-	-				
_										-
			-					-		
1.00	Cor - 100			-				1		
Record	No. 1									
Pence :	In	Edit Nos		1.	lar.	_	w . [D: la	-
rence.	IP 45	Luic Nos II		L.	25		••• 2t	13	v. ju	
		Record No. 1 rence : [P 45]								

Now Click the EXIT button to leave this window.

You are back to Edit Menu.

Similarly you can display / Edit / Copy / Delete records from other sections by double clicking the required section.

STEP NO. 4 IS OVER.


STEP NO. 5

NOTE: DO NOT EDIT MATERIAL OR LABOUR COEFFICIENTS UNLESS YOU HAVE SOME VALID REASONS TO DO SO.

THE MATERIAL COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL CEMENT, SAND, AGGREGATE & BRICK QUANTITIES ONLY.

THE LABOUR COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL MASON, CARPENTER, SKILLED LABOUR, UNSKILLED LABOUR & FOREMAN QUANTITIES.

THE ABOVE COEFFICIENTS ARE ALSO USED IN CALCULATION OF MONTHLY MATERIAL, LABOUR & CASH FLOW REQUIREMENTS AFTER USER HAS PREPARED THE PROJECT BAR CHART.



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Edit Coefficients option in the MENU bar. Here you will have two options.


Material Coefficients

Labour Coefficients

Click the Material Coefficients option. The following window will open.

Open				? ×
Look in: 🔂	1q	• E	2	
a1.QTY Q2.qty QTY.qty				
, File <u>n</u> ame:	QTY.qty		_	<u>O</u> pen
Files of type:	(*.QTY)		•	Cancel
	C Open as read-only			1.

Now click QTY file & click open. A new window with all Sections will appear as follows. The heading is Edit / Delete Material Coefficients - Double Click any option.



 Now double click "Section E: Reinforced Cement Concrete ".
 A new window will appear as follows, listing Material Coefficients of items having Cement, Sand, Aggregate & Brick Components.

DISPLAY/EDIT OF MATERIAL COEFFICIENTS

Section E: Reinforced Cement Concrete

Date : 9/8/05

em_ID	Item No.	Item	Unit	Cement	Sand	Aggreg	Brick	1
	E1	RCC 1:1:2 UP TO PLINTH LEVEL	M3	12.2	0.45	0.45		
	E2	RCC 1:1.5:3 UP TO PLINTH LEVEL	M3	8.0	0.441	0.882		
	E3	RCC 1:2:4 UP TO PLINTH LEVEL	M3	6.4	0.47	0.94		_
	E4	RCC WALLS IN SUPER STRUCTURE 1:1:2	M3	12.2	0.45	0.90		
	E5	RCC WALLS IN SUPER STRUCTURE 1 : 1	M3	8.0	0.441	0.882		
	E6	RCC WALLS IN SUPER STRUCTURE 1:2:4	M3	6.4	0.47	0.94		
	E7	RCC COLUMNS IN SUPER STRUCTURE 1 :	M3	12.2	0.45	0.90		
	E8	RCC COLUMNS IN SUPER STRUCTURE 1 :	M3	8.0	0.441	0.882		
	E9	RCC COLUMNS IN SUPER STRUCTURE 1 :	M3	6.4	0.47	0.94		
	E10	RCC SLABS IN SUPER STRUCTURE 1:2:4	M3	6.4	0.47	0.94		
	E11	RCC SLABS IN SUPER STRUCTURE 1 : 1.5	M3	8.0	0.441	0.882		
	E12	RCC SLABS IN SUPER STRUCTURE 1:1:2	M3	12.2	0.45	0.90		
	E13	RCC BEAMS IN SUPER STRUCTURE 1:2:4	M3	6.4	0.47	0.94		
	E14	RCC BEAMS IN SUPER STRUCTURE 1 : 1	M3	8.0	0.441	0.882		
	E15	RCC BEAMS IN SUPER STRUCTURE 1:1:2	M3	12.2	0.45	0.90		
	E16	RCC ARCH IN SUPER STRUCTURE 1:2:4	M3	6.4	0.47	0.94		
	E17	RCC ARCH IN SUPER STRUCTURE 1:1.5:3	M3	8.0	0.441	0.882		
	E18	RCC DOMES / FOLDED PLATES IN SUPER	M3	6.53	0.48	0.96		
	E19	RCC DOMES / FOLDED PLATES IN SUPER	M3	8.16	0.45	0.90		
	E20	RCC SHAFTS IN SUPER STRUCTURE 1:2	M3	6.53	0.48	0.96		
	E21	RCC SHAFTS IN SUPER STRUCTURE 1 : 1	M3	8.16	0.45	0.90		
	E22	RCC SHAFTS IN SUPER STRUCTURE 1 : 2	M3	6.53	0.48	0.96		
	E23	RCC SHAFTS IN SUPER STRUCTURE 1 : 1	M3	8.16	0.45	0.90		
	E24	RCC WORK IN WELL-STEINING 1:2:4	M3	6.53	0.48	0.96		
	F95	DCC MODE IN MELL STEINING 4 + 4 5 + 3	M3	8 46	8.45	n on		
		EXIT	UPDAT	E		PRINT		

The above window can perform the following functions.

• By Clicking " PRINT " button, all the records will be printed.

The most important option available here is Editing. At the base of window there is a heading in RED which says "Edit Material Coefficients E1 ".

Just change the various fields (Values in the text boxes) & it will get reflected in the selected ROW above.

Click " UPDATE " button to refresh changes.

Now Click the EXIT button to leave this window.

You are back to Section Menu.

Project No : 4305

Similarly you can Edit materials Coefficients of other sections by double clicking the required selected section.

STEP NO. 5 IS OVER.


STEP NO. 6

NOTE: DO NOT EDIT MATERIAL OR LABOUR COEFFICIENTS UNLESS YOU HAVE SOME VALID REASONS TO DO SO.

THE MATERIAL COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL CEMENT, SAND, AGGREGATE & BRICK QUANTITIES ONLY.

THE LABOUR COEFFICIENTS ARE USED FOR CALCULATION OF TOTAL MASON, CARPENTER, SKILLED LABOUR, UNSKILLED LABOUR & FOREMAN QUANTITIES.

THE ABOVE COEFFICIENTS ARE ALSO USED IN CALCULATION OF MONTHLY MATERIAL, LABOUR & CASH FLOW REQUIREMENTS AFTER USER HAS PREPARED THE PROJECT BAR CHART.



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Edit Coefficients option in the MENU bar. Here you will have two options.


Material Coefficients

Labour Coefficients

Click the Labour Coefficients option. The following window will open.

Open				?	х
Look in: 🕞	19	• E	2	🛃 🛅 🖻	
a1.QTY Q2.qty QTY.qty					
File <u>n</u> ame: Files of <u>type</u> :	QTY.qty (*.QTY)			<u>O</u> pen Cancel]
	C Open as read-only				

Now click QTY file & click open. A new window with all Sections will appear as follows. The heading is Edit / Delete Labour Coefficients - Double Click any option.



Now double click " Section E: Reinforced Cement Concrete ". A new window will appear as follows, listing Labour Coefficients of items having Mason, Carpenter, Skilled Labour, Unskilled Labour & Foreman Components.

DISPLAY/EDIT LABOUR COEFFICIENTS

Section E: Reinforced Cement Concrete

Date : 9/8/05

tem_ID	Item_no	Item	Unit	Mason	Carpent	Skill	Unskilled	Foreman	
	E1	RCC 1:1:2 UP TO PLINTH LEVEL	M3	0.17			2.97	0.05	
	E2	RCC 1:1.5:3 UP TO PLINTH LEVEL	M3	0.17			2.97	0.05	
	E3	RCC 1:2:4 UP TO PLINTH LEVEL	M3	0.17			2.97	0.05	
	E4	RCC WALLS IN SUPER STRUCTURE 1	M3	0.23			4.5	0.05	\square
	E5	RCC WALLS IN SUPER STRUCTURE 1	M3	0.23			4.5	0.05	T
	E6	RCC WALLS IN SUPER STRUCTURE 1	M3	0.23			4.5	0.05	П
	E7	RCC COLUMNS IN SUPER STRUCTUR	M3	0.23			4.5	0.07	П
	E8	RCC COLUMNS IN SUPER STRUCTUR	M3	0.23			4.5	0.07	П
	E9	RCC COLUMNS IN SUPER STRUCTUR	M3	0.23			4.5	0.07	
	E10	RCC SLABS IN SUPER STRUCTURE 1	M3	0.24			3.47	0.05	
	E11	RCC SLABS IN SUPER STRUCTURE 1	M3	0.24			3.47	0.05	П
	E12	RCC SLABS IN SUPER STRUCTURE 1	M3	0.24			3.47	0.05	Т
	E13	RCC BEAMS IN SUPER STRUCTURE 1	M3	0.20			3.97	0.07	T
	E14	RCC BEAMS IN SUPER STRUCTURE 1	M3	0.20			3.97	0.07	Т
	E15	RCC BEAMS IN SUPER STRUCTURE 1	M3	0.20			3.97	0.07	Т
	E16	RCC ARCH IN SUPER STRUCTURE 1 :	M3	0.30			5.27	0.125	
	E17	RCC ARCH IN SUPER STRUCTURE 1 :	M3	0.30			5.27	0.125	Т
	E18	RCC DOMES / FOLDED PLATES IN SU	M3	0.30			5.27	0.125	Г
	E19	RCC DOMES / FOLDED PLATES IN SU	M3	0.30			5.27	0.125	Г
	E20	RCC SHAFTS IN SUPER STRUCTURE	M3	0.23			4.5	0.12	
	E21	RCC SHAFTS IN SUPER STRUCTURE	M3	0.23			4.5	0.12	Г
	E22	RCC SHAFTS IN SUPER STRUCTURE	M3	0.23		1	4.5	0.12	
	E23	RCC SHAFTS IN SUPER STRUCTURE	M3	0.23			4.5	0.12	
	E24	RCC WORK IN WELL-STEINING 1:2:4	M3	0.3			5.27	0.12	

The above window can perform the following functions.

• By Clicking " PRINT " button, all the records will be printed.

• The most important option available here is Editing. At the base of window there is a heading in RED which says " Edit Labour Coefficients for item no. E1 ". Just change the various fields (Values in the text boxes) & it will get reflected in

the selected ROW above.

Project : 4305

Click " UPDATE " button to refresh changes.


Now Click the EXIT button to leave this window.

You are back to Section Menu.

Similarly you can Edit Labour Coefficients of other sections by double clicking the required selected section.

STEP NO. 6 IS OVER.

STEP NO. 7



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Summary option in the MENU bar. The following options will open up.

Sectionwise Quantities / Costs Total Cost Sectionwise Cement/Sand/Agg/Brick Total Cement/Sand/Agg/Brick Sectionwise Labour Total Labour Consumption Reinforcement Break up Total Structural Steel MB Section Break up MC Section Break Up Angle Section Break Up Plate Thickness Break up Tube Section Break Up

All the above options display the various quantities & cost aspect of a given project. I have added random quantities & appropriate rates to various items in sections.

When I click the "Total Cost " option, following window is displayed.

Open					? ×
Look jn: 🧲) 1q	- 🗈			
 q1.QTY Q2.qty QTY.qty 					
File <u>n</u> ame: Files of <u>type</u> :	QTY.qty (*.QTY)		- -	-	pen Incel
	C Open as read-only				1

Click QTY file & click open. A new window with all Sectional costs appear as follows.

SUMMARY OF PROJECT COST


Organization : ABC CONSULTANTS	Client : M/S Real Estate Corp.					
Project : G + 1 Storey Bldg.	Project No: 4305					
Building / Structure : B1	Date: 9/8/05					
Total Project Cost : 1364074.98	Total Overhead : 109125.99					
Total Taxes : 54562.99	Total Profit : 109125.99					

SECTION	COST	OVERHEAD	TAX	PROFIT	% TOTAL	
Section A: Preparatory Work	62500	5000	2500	5000	4.58	
Section B: Excavation	46875	3750	1875	3750	3.43	
Section C: Mortars	116250	9300	4650	9300	8.52	
Section D: Plain Cement Concrete	84375	6750	3375	6750	6.18	
Section E: Reinforced Cement Concrete	88399.98	7071.99	3535.99	7071.99	6.48	
Section F: Brick Masonry Work	33750	2700	1350	2700	2.47	
Section G: Stone Work	45000	3600	1800	3600	3.29	
Section H: Marble Work	13500	1080	540	1080	.98	
Section I: Wood Work	21875	1750	875	1750	1.6	
Section J: Door/Window Hardware	18750	1500	750	1500	1.37	
Section K: Structural Steel Work	135300	10824	5412	10824	9.91	
Section L: Flooring and Skirting	75000	6000	3000	6000	5.49	
Section M: Roofing/Ceiling	93750	7500	3750	7500	6.87	
Section N: Finishing/Plastering	31250	2500	1250	2500	2.29	
Section P: Painting/Polishing	25000	2000	1000	2000	1.83	
Section Q: Building Repairs	0	0	0	0	0	
Section R: Dismantling/Demolishing	0	0	0	0	0	
Section S: Miscellaneous Works	30000	2400	1200	2400	2.19	
Section T: Road Work	62500	5000	2500	5000	4.58	
Section U: Horticulture/Landscaping	25000	2000	1000	2000	1.83	
Section V: Sanitary Installations	100000	8000	4000	8000	7.33	
Section W: Water Supply	56250	4500	2250	4500	4.12	
Section X: Drainage/Sewage	18750	1500	750	1500	1.37	
Section Y: Pile Work	130000	10400	5200	10400	9.53	
Section 7: Water Proofing	50000	4000	2000	4000	3 66	

Similarly when you click other options appropriate window will open & display the required parameters.

STEP NO. 7 IS OVER.

STEP NO. 8



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Graphics option in the MENU bar. The following window will open up.


Open			? ×
Look in: 🔂) 1q	💌 🖻 💆	
a1.QTY Q2.qty			
DTY.qty			
J	-		
File <u>n</u> ame:	QTY.qty		<u>O</u> pen
Files of type:	(*.QTY)	•	Cancel
	🗖 Open as <u>r</u> ead-only		//

Click QTY file & click open. A new window will open Displaying Chart Menu as under.

Total Cost :	: Pie Chart
Total Cost :	
Total Overl	heads : Bar Chart
Total Profit	t : Bar Chart
Total Taxe:	s : Bar Chart
Cement/Sa	ind/Agg/Brick : Bar Charl
Total Labor	ur : Bar Chart
Total Labo	ur : Pie Chart
Reinforcem	ients : Pie Chart
Reinforcem	ients : Bar Chart
MB Section	: Pie Chart
MB Section	: Bar Chart
MC Section	: Pie Chart
MC Section	: Bar Chart

All the above options display the various quantities & cost aspect of a given project in Pie or Bar Chart form.


When I double click the "Total Cost : Pie Chart " option, following Pie Chart is displayed.



Similarly when you double click other options, appropriate windows will open & display the required Pie / Bar Chart.

STEP NO. 8 IS OVER.

STEP NO. 9



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Specs option in the MENU bar. The following options will open up.

SPECIFICATIONS









BUILDING REPAIRS

DISMANTLING & DEMOLISHING



e <u>Roads</u>

HORTICULTURE & LANDSCAPING



WATER SUPPLY

DRAINAGE & SEWAGE

PILE WORK






Click on any of the above Link & Specification of selected topic will be displayed.

STEP NO. 9 IS OVER.

LEARN QTY STEP BY STEP

STEP NO. 10



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the Forms_1 option in the MENU bar. The following options will open up.

Measurement Sheet
R A Bill - CPWD Item Rate
R A Bill - CPWD Lump Sum
Advance Payment - CPWD
R A Bill - General
Projected Delay Report
Projected Profit
Projected Material Consumption
Projected Labour Consumption
Actual Delay Report
Actual Profit / Loss
Actual Material Consumption
Actual Labour Consumption
Profit Control
Material Control
Labour Control
Daily Progress Report
Material Inward Report
Material Transfer Receipt
Material Issue Slip
Daily Store Consumption
Daily Departmental Labour Slip
Watchman Report - Material
Watchman Report - Visitors
Inspection Report
Indent Slip
Pending Requisitions
Material Consumption Statement
Cement Consumption Statement

If you click the Forms_2 option then following graphics will appear.

Electricity Consumption Statement

Water Consumption Statement Machinery Status Report Machinery Maintainance Report Excess Material List Progress Report Material Planning Schedule Activity Schedule Crash Cost Schedule Calendar Date / Working Day Material Order/Receipt Schedule Labour Payment Schedule The Forms_1 & Forms_2 options display various typical forms, formats or templates generally used in construction industry. A typical quantity measurement sheet is displayed as under.

ORGANIZATION Address -1

Address -2

Phone No:

Cell:

Project:

Dated: xx/xx/0x

Project No:

Client:

Building / Structure:

MEASUREMENT / QUANTITY SHEET

SN	Item No	Item - Description	Unit	Nos	L	w	D	QTY
1	B1	Rough Excavation - area a 1	M3	1	10	10	.5	
2	B1	Rough Excavation - area a2	M3	2	5	5	1	
3	B2	Banking - area a 1	M3	1	2	2	.3	
4	B2	Banking - area a2	M3	2	3	3	.4	
5				8	8 8		8	
6				1	1 - T			
7			- 8	<u>, </u>			- 6	
8			_					
9			100			Ĩ		
10			- 8		3		6	
11								
12			- K	1	1 - 1	1 3	- 3	
13								
14			- (š		3 3	- 3	- 3	
15								
16					· · · ·			
17				8	8 - 8		- 8	
					3 8			8


SECTION B - EXCAVATION

All the above Forms / Formats / Templates are in M. S. WORD format. In case of any difficulty in opening the above documents, user can directly access the above files from C: \ Program files \ QTY \ Form directory.

STEP NO. 10 IS OVER.

LEARN QTY STEP BY STEP

STEP NO. 11



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the FILE option in the MENU bar. The following window will open.

- File Make New File Delete File Copy File Edit Project File Export QTY to Excel Gnatt Chart / Cash Flow Warranty Read Me Calculator Exit
- Now click Copy File option. A new window will appear as follows, asking for the name of the File to be copied.

Open			? ×
Look in: 🔂	19	💽 🖻 💆	1 📺 🔳
a1.QTY Q2.qty			
l File <u>n</u> ame:	QTY.qty		<u>O</u> pen
Files of <u>type</u> :	(*.QTY)	<u>·</u>	Cancel

Now click QTY file & click open. A new window will appear as follows, asking for the name of the destination file.

File Copy	×
Enter Destination File name without Extension	ОК
	Cancel
P_231	

Give the destination file name as P_231. Press " OK " button. A new message window will appear as follows.



- The above message confirms the copying of all respective files to new P_231 file. Note that original file QTY is intact. Press " OK " button to exit.
- Again Now click Delete File option. A new window will appear as follows, asking for the name of the File to be deleted.

Open		? ×
Look jn: 🔂	🛚 1q 📃 🖻 💆	
P_231.qty a q1.QTY Q2.qty QTY.qty		
File <u>n</u> ame:	P_231.qty	<u>O</u> pen
Files of <u>type</u> :	(*.qty)	Cancel
	C Open as read-only	1

Select P_231 file & click " Open " button. A new window will open as follows, requiring confirmation.

File Deletion ?		×
Do you want delete the	File C:\1q\P_2	31.qty
OK]	Cancel	

Click the " OK " button, again a new window will open as follows, confirming deletion of P_231 qty & item files.



Now click Edit Project File option. A new window will appear as follows, asking for the name of the project File to be Edited.

)pen					?
Look jn: 🧲) 1g	•	E	2 🖻	
🖹 q1.QTY					
Q2.qty					
File <u>n</u> ame:	QTY.qty				<u>O</u> pen
File <u>n</u> ame: Files of <u>t</u> ype:	QTY.qty (*.QTY)				<u>O</u> pen Cancel

Now click QTY file & click open. A new window will appear as follows, enabling user to change the various project parameters.

🖷, Project File : Edit Project Deta	ils		×
File Name : C:\1q\QTY.qty			Date: 10/8/05
Organization :	ABC CONSULTANTS		
Project :	G + 1 Storey Bldg.		
Project No :	4305		
Client ID :	M/S Real Estate Corp.		
Building / Structure ID :	B1	-	
Project Duration in Months :	36	Project Over Head in %	10
Taxes in %	5	Profit Margin in %	10
Rate per Cement Bag	200	Rate per M3 of Sand	600
Rate per M3 of Aggregates	600	Rate per Brick	1.0
Mason Wage/day	250	Carpenter Wage / day	250
Skill labour Wage / day	250	Un Skilled Labour Wage	180
Foreman Cost / day	350	Mobilization Advance in 9	% 5
Recovery of Advance in %	5	Security Deposit in %	5
EXIT		PR	INT

After you have completed editing the various project parameters click " EXIT " button.

Now click Export QTY to EXCEL option. A new window will appear as follows, asking for the name of the project File to be Exported to EXCEL.

Open				? ×
Look in: 🔂	1q	- 🗈	🥑 🖻	
a1.QTY Q2.qty				
File <u>n</u> ame:	QTY.qty			<u>O</u> pen
Files of type:	(*.QTY)]	-	Cancel
	C Open as <u>r</u> ead-only			1

Now click QTY file & click open. A new window will appear as follows, indicating that all the QTY files are copied to a new file with .TXT extension.


Export to	EXCEL :
٩	All Quantity Files are copied to Document File C:\1q\QTY.TXT User can open this Text file in EXCEL as Comma Seperated Text File.
	ОК

User can open this Text file in EXCEL as comma separated Text File.

STEP NO. 11 IS OVER.

LEARN QTY STEP BY STEP

STEP NO. 12



Refer the graphics above. The Menu bar contains following options.

I. File II. Edit Items III. Add Record IV. Edit Quantities V. Edit Coefficients VI. Summary VII. Graphics VIII. Specs IX. Forms_1 X. Forms_2

Click the FILE option in the MENU bar. The following window will open.

- File Make New File Delete File Copy File Edit Project File Export QTY to Excel Gnatt Chart / Cash Flow Warranty Read Me Calculator Exit
- Now click Gnatt Chart / Cash Flow option. A new window will appear as follows, asking for the file name.

Open			? ×
Look in: 🔂	1q	- 🖻 🜌	📸 🔳
a1.QTY Q2.qty			
, File <u>n</u> ame:	QTY.qty		<u>O</u> pen
Files of type:	(*.QTY)	•	Cancel
	C Open as read-only		//

Now click QTY file & click open. A new window will appear as follows, showing empty Gnatt / Bar Chart.

Gnatt Chart : D	isplay / Edit /	Deletion of	Bars
-----------------	-----------------	-------------	------

Project	No:	4305	
---------	-----	------	--

8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24	_	Contrast (Marca	£.,		007		307 - 0		Sec. 1	20	101 17	10	Tin	ne in	Mon	ths	a		0	327 - 1		o) v	c	01 10	o – 7	a 1
		Section / Item	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
	1	A / Mobilization												100												
	2	B / Excavation																								
	3	C / Mortar	5 -																							
	4	D/PCC	8																							
	5	E/RCC																								
	6	F / Brick Work	2																							
	7	G / Stone Work	5																							
	8	H / Marble Work																								
	9	1/Wood Work	2																							
	10	J/D_W Hardware	8																							
	11	K / Str. Steel																								
	12	L / Flooring	1																							-
	13	M / Roofing	S																							
	14	N / Finishing																								
	15	P / Painting	1																							
	6	Q / Bldg. Repairs	<u> </u>																							
	17	R / Demolishing																								
	18	S / Misc.	8																							-
	19	T / Roads	8																							
	20	U/Landscaping																								
	21	V / Sanitary	3																							
	22	W / Water Supply	2																							
	23	X / Drainage																								
	24	Y / Pilling	8																							
	25		Q																							
	26	AA / Bridge Work																								
	23 24 25 26																									
		_					/							. Since D					_				8			
ribution Edit Bar Chart Exit Print		Landsca	ping	9	5	anita	ry	W	/ater	r Sup	ply	0)rain	age		Pillin	9	H2	O Pr	oofir	ıg	Br	idge			load
Supply Drainage Pilling H20 Proofing Bridge	D	/W Hardware	Str.	Ste	el	Flo	oring	g	Ro	ofing		Finis	hing	1	Paint	ing	R	epai	ir	De	molis	h	Mi	sc.		
Supply Drainage Pilling H20 Proofing Bridge Road	_	obilization Exe														1.1				1000			1.1			

Project: G +1 Storey Bldg.

Now let us start constructing Gnatt / Bar Chart.

Click "Mobilization "button situated at the left bottom corner of chart. The following window will appear asking for "Enter Start of Mobilization ". Type 0 & press "OK ".

×
OK
Cancel

Again a new window will appear asking for "Enter End of Mobilization ". Type 1 & press " OK ". This window is displayed as under.

Finish of Bar not > 24	×
Enter End of Mobilization	Cancel
1	

Now you will see a RED BAR is displayed between 0 and 1 on the Mobilization ROW. Similarly you can prepare the complete GNATT / BAR CHART by clicking various activity buttons such as Excavation, Mortar, PCC, RCC etc.... I have completed the BAR CHART for the whole project as follows.

	ct No: 4305	Project : G + 1 Storey Bldg.	Date: 10/8/05
		Time in Months	or an we see
	Section / Item	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	21 22 23 24
	A / Mobilization		
	B / Excavation		
	C / Mortar		
	D/PCC		
	E/RCC		
	F / Brick Work		
	G / Stone Work		
	H / Marble Work		
	I / Wood Work		
П	J/D_WHardware	d	
ī	K / Str. Steel		
2	L / Flooring		
	M / Roofing		
1	N / Finishing		
1	P / Painting		-
	Q / Bldg. Repairs		
	R / Demolishing		
	S / Misc.		
П	T / Roads		
_	U/Landscaping		
_	V / Sanitary		
	V / Sanitary W / Water Supply		and the second
1			
2	W / Water Supply X / Drainage Y / Pilling		
1 2 3	W / Water Supply X / Drainage Y / Pilling Z / H2o Proofing		
1 2 3	W / Water Supply X / Drainage		
1 2 3 4 5	W / Water Supply X / Drainage Y / Pilling Z / H2o Proofing AA / Bridge Work		
1 2 3 4 5	W / Water Supply X / Drainage Y / Pilling Z / H2o Proofing AA / Bridge Work	Cash Flow / Material / Men : Distribution Edit Bar Chart Exit Print	ridge
1 2 3 4 5 5	W / Water Supply X / Drainage Y / Pilling Z / H2o Proofing AA / Bridge Work	Cash Flow / Material / Men : Distribution Edit Bar Chart Exit Print	ridge Road
0 1 2 3 4 5 6	W / Water Supply X / Drainage Y / Pilling Z / H2o Proofing AA / Bridge Work	Cash Flow / Material / Men : Distribution Edit Bar Chart Exit Print	ridge

In case you have made any mistake or wants to change the Bar Chart, just click " Edit Bar Chart " button. Following window will appear.

Section	Item	Bar_Start	Bar_End
A	Mobilization	0	1
8	Excavation	1	3
C	Mortar	2	3
D	PCC	2	4
E	RCC	4	7
F	Brick Masonry	7	9
G	Stone Work	8	9
н	Marble Work	9	10
C .	Wood Work	10	12
1	D/W Hardware	12	13
ĸ	Str. Steel	13	15
0	Flooring	14	16
ч	Roofing	16	19
N	Finishing	18	20
P	Painting	20	23
5	Misc.	22	23
г	Road Work	23	24
J	Landscaping	17	19
v	Sanitary	18	21
W	Water Supply	19	22
x	Drainage	22	24
Y	Pilling	2	5
2	Water Proofing	23	24
Edit Bar S	itart : 0	Edi	t Bar End :

Gnatt Chart

- Just Edit Bar Start or Edit Bar End and click on UPDATE button to register changes. Note that bar end should always be greater then bar start. If you want to delete any activity, (BAR) just take mouse to that ROW & click (select) and press the "REMOVE " button. Now you will notice that the selected activity has disappeared from this edit menu as well as the corresponding RED BAR has also been removed from the BAR CHART. Click Exit.
- Click on the " Cash Flow / Material / Men distribution : " Button to display these parameters. A new window will appear as shown in following 3 nos. of graphics.

51

COST DISTRIBUTION / CUMULATIVE CASH FLOW :

Organization : ABC CONSULTANTS

Project : G + 1 Storey Bldg.

Building / Structure : B1

Client : M/S Real Estate Corp.

Project No: 4305

Date: 10/8/05

Month	1	2	3	4	5	6	7	8
Value	62500	23437.5	225208.33	85520.83	72799.99	29466.66	29466.65	16875
% Cumulative	4	6	22	29	34	36	38	39
Over Head	5000	1875	18016.66	6841.66	5823.99	2357.33	2357.33	1350
Тах	2500	937.5	9008.33	3420.83	2911.99	1178.66	1178.66	675
Profit	5000	1875	18016.66	6841.66	5823.99	2357.33	2357.33	1350
Cement - Bag	0	0	142.58	142.58	37.86	32.53	32.53	16.87
Sand - M3	0	0	5.45	5.45	1.59	1.2	1.19	3.64
Aggregate	0	0	10.91	10.91	1.98	1.2	1.19	0
Brick - No	0	0	0	0	0	0	0	6750
Mason - No	0	0	2.08	2.08	0.62	0.45	0.45	8.1
Carpenter	0	0	0	0	0	0	0	0
Skill Lab - No	0	0	0.26	0.26	2.65	2.39	2.39	0
Unskill Lab	9.19	133.5	255.4	36.1	16.04	10.31	10.31	24.36
Foreman - No	0	12	18.82	0.82	0.59	0.32	0.32	0.23
Cash Param								
Cost	57499.99	21562.5	207191.66	78679.16	66975.99	27109.32	27109.31	15524.99
Labour Cost	1654.2	28230	53144	7370	3911.2	2677.8	2677.8	6490.3
Material + 0	55845.79	-6667.5	154047.66	71309.16	63064.79	24431.52	24431.51	9034.68
Adv. Recovery	0	3125	1171.87	11260.41	4276.04	3639.99	1473.33	1473.33
SD Recovery	0	3125	1171.87	11260.41	4276.04	3639.99	1473.33	1473.33
Cash Flow	66549.54	38723.75	13341.01	54610.86	56359.25	56136.67	55547.35	51145.53
4								

Read Me

5 Curve

Print

Exit

COST DISTRIBUTION / CUMULATIVE CASH FLOW :

Organization : ABC CONSULTANTS

Project : G + 1 Storey Bldg.

Building / Structure : B1

Client: M/S Real Estate Corp.

Project No: 4305

Date: 10/8/05

9	10	11	12	13	14	15	16	17
61875	13500	10937.5	10937.5	18750	67650	105150	37500	31250
44	45	46	47	48	53	61	63	66
4950	1080	875	875	1500	5412	8412	3000	2500
2475	540	437.5	437.5	750	2706	4206	1500	1250
4950	1080	875	875	1500	5412	8412	3000	2500
135.67	39.76	0	0	0	0	464	464	0
29.06	5.36	0	0	0	0	3.45	3.45	0
0	0	0	0	0	0	0	0	0
6750	0	0	0	0	0	4237.5	4237.5	0
80.09	120	0	0	0	0	8.25	8.25	0
0	0	42.78	42.78	4	0	0	0	7.5
0	0	0	0	0	53.89	53.9	0	5
178.44	135.93	42.78	42.78	2	82.9	99.85	16.95	1
1.89	12.33	0	0	0	0.29	0.59	0.3	1.21
56924.99	12419.99	10062.5	10062.5	17250	62237.99	96737.99	34500	28749.99
52803.19	58782.9	18395.4	18395.4	1360	28496	33717	5218.5	3728.5
4121.79	-46362.91	-8332.91	-8332.91	15890	33741.99	63020.99	29281.5	25021.49
843.75	3093.75	675	546.87	546.87	937.5	3382.5	5257.5	1875
843.75	3093.75	675	546.87	546.87	937.5	3382.5	5257.5	1875
4495.15	-2722.05	37395.46	37176.73	53993.4	26482.4	19908.41	46303.92	47043.92

Read Me

S Curve

Print

Exit

COST DISTRIBUTION / CUMULATIVE CASH FLOW :

Organization : ABC CONSULTANTS

Project : G + 1 Storey Bldg.

Building / Structure : B1

Client : M/S Real Estate Corp.


Project No: 4305

Date: 10/8/05

18	19	20	21	22	23	24	Total
43750	92708.33	67708.33	60416.66	27083.33	47708.33	121875	1364074.94
69	76	81	85	87	91	100	100
3500	7416.66	5416.66	4833.33	2166.66	3816.66	9750	109125.94
1750	3708.33	2708.33	2416.66	1083.33	1908.33	4875	54562.95
3500	7416.66	5416.66	4833.33	2166.66	3816.66	9750	109125.94
0	0	0	0	0	17.76	292.16	1818
0	0.51	0.51	0	0	5.12	27.77	93
0	0	0	0	0	2.9	4	33
0	0	0	0	0	0	0	21975
0	3	3	0	0	6.35	142.34	385
7.5	7.5	0	0	0	0	0	112
5	18.33	20.03	21.36	8.03	1.33	0	194
21	38.66	24.36	14.03	7.36	24.46	297.25	1524
2.21	2.29	1.57	1.5	1.5	1.02	57.42	117
40250	85291.66	62291.66	55583.32	24916.66	43891.66	112124.99	1254948.94
7678.5	14967.8	10691.8	8390.4	3857.3	6679.8	109187	488504.79
32571.5	70323.86	51599.86	47192.91	21059.36	37211.86	2937.99	766444.14
1562.5	2187.5	4635.41	3385.41	3020.83	1354.16	2385.41	62109.93
1562.5	2187.5	4635.41	3385.41	3020.83	1354.16	2385.41	62109.93
42468.92	34304.61	36726.46	37673.71	40998.49	37634.34	-65827.01	109126.12

The project duration of maximum of 24 months is allowed at a time. Note that Cash Flow / Material / Men distribution is entirely dependent on Gnatt Chart. If you prepare a Bar Chart of 12 months duration & only few required activities then Cash Flow / Material / Men distribution will correspond to 12 months duration & those selected activities.

Lastly Click on the "S CURVE " button. The "S CURVE " will be displayed as under.



Click EXIT " 3 " times to return to main menu.

STEP NO. 12 IS OVER.

OTHER SOFTWARES:

- SUPER CIVIL CD Single Point Solution To Your Civil Engineering Needs
- SUPER RATE ANALYSIS Rate Analysis Of 1299 Nos. Of Civil Engineering Items
- **<u>2D FRAME ANALYSIS</u>** Discover The Beauty Of Structural Analysis
- RCF A Software for Analysis, Design, Estimation & Costing of RCC Floors
- <u>SSF</u> Analysis, Design, Estimation & Costing of Steel Buildings, revised as per IS 800 : 2007
- SUPER REAL VALUATION A Software For Immovable Properties
- ROADS Pavement Design & Rate Analysis Of Road Items
- <u>ROAD ESTIMATE</u> Quantity Estimation & Cost, Project Control For Road
- ELECTRIC COST Costing, Project Control & MDS For Electrical Projects
- HVAC COST Costing, Project Control & Design For HVAC Engineers
- BILLING JI A Database Management Software For General Billing
- RABILL A Database Management Software For Item Rate Contract Billing
- BUILDERS BILL A Database Management Software for Billing of Lump sum Contracts
- BID ANALYSIS A Software For Technical & Commercial Tender Analysis
- <u>RAFT FOUNDATION</u> Analysis, Design, Estimation, Costing & Drawing of RCC Raft Foundation
- STEEL_2007 Limit State design of Steel as per IS 800 : 2007
- **<u>SITE CONTROL</u>** A Management Software for Resource Control At Site.
- **DESIGN & DRAWING CONTROL** A DBM Software for Control of Design & Drawing Manhours.
- <u>COMPOSITE</u> A Software for Analysis, Design, Costing & Drawing of Composite Floor Buildings
- **INSTA COST** A Software for Estimating Project Cost & Tender SOQ Instantly
- FLAT SLAB A Software for Analysis, Design, Estimation, Costing & Drawings of Flat Slabs
- FLAT RAFT A Software for Analysis, Design, Estimation, Costing & Drawings of Rigid RCC Flat Rafts
- **OPTIMIZE_BAR** A Software for Optimization of Reinforcements from Existing Bar Bending Schedule
- **OPTIMIZE STEEL** A Software for Optimization of Steel Sections from Existing Fabrication Drawing
- AutoQty A Software for Automatic Quantity & Cost Estimation from AutoCAD Drawings